

HART™



CORN HOLE BOARDS

@A.Dabbled.Dwelling

PROJECT PLAN

Skill Level: Intermediate

Materials

Item	Qty
1/2" or 3/4" thick plywood sheet	1
1x4x8 board	4
Wood glue	1
Wood screws	32
Nails	
Bean bags	8
6" Hole Saw	
Stain	
Polycrylic	
Painters Tape	
Star Stickers	

Tools Used



Circular Saw



Drill/Driver



Orbit Sander



6" Hole Saw

Also Needed: Brad Nailer



Battery Tip: A 4.0 Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

Lumber Cut List

Board	Description	Cut to	Qty
4x8'	plywood	24"x48"	2
1x4x8		24"	4
1x4x8		46.75"	4

Assembly Instructions

Step 1

Assemble your 1x4s into (2) 2x4' frames by drilling pilot holes and wood screws at the corners.

Step 2

Glue the cut plywood sheets to the top of the assembled frame and secure with brad nails.

Step 3

Drill a 6" hole with a hole saw. The center will be 9" from the top of your board and 12" from the side.

Step 4

Sand down any glue drips and rough spots. Sand the corners and inside of the 6" hole to avoid any snags to the bean bags.

Step 5

Cut 4 legs out of 1x4s so that your boards sit 12 inches from the ground. Use screws to attach to the inside/underneath of the frame. Cut the bottoms of the legs at 15 degrees.

Step 6

Whitewash the entire board to seal the grain and tape off your desired pattern, then start staining.

Step 7

Remove tape and seal with a glossy Polycrylic to give your boards a nice finish and "sliding texture" for the bean bags. Enjoy!