

# HART™



Custom Headboard  
@VirginiaHomeImprovements

## PROJECT PLAN

**Skill Level:** Intermediate

# Materials

Item	Qty
Piano Upper Panel	1
1x3x8* Board	12
Screws	
Wood Stain	
Wood Glue	
Wood Filler	

\* Board Dimensions are "nominal". Actual dimensions are smaller due to lumber industry standards. Cuts are actual length.

A select/premium board or plywood comes with a smoother surface finish. It is clear or has very few tight knots, and it will have straight and sharp edges. This grade of wood pairs well with other boards or panels better and requires less time to sand and finish.

# Tools Used



Miter Saw



Drill / Driver



Orbital Sander



Pencil



Safety Glasses



Tape Measure

Battery Tip: A 4.0 Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

# Assembly Instructions

---

## Step 1

Re-purpose / thrift an old piano upper panel.

---

## Step 2

Cut 1x3s to frame the panel. Miter ends to 45° and screw together.

---

## Step 3

Build out the frame to desired width (twin, queen, or king).

---

## Step 4

Fill in gaps with wood filler.

---

## Step 5

Sand the whole headboard with 120 grit sand paper.

---

## Step 6

Stain the headboard with desired stain.