



Patio Privacy Screen

Kayla | [@itshoneydone](https://www.instagram.com/itshoneydone)

PROJECT PLAN

Finished Dimensions: Varies based on Desired Size

Skill Level: Intermediate

Materials

Item	Qty
1 x 6 Pressure Treated Pine Boards	20
2" Galvanized Brad Nails	1 Package
4 x4 Pressure Treated Pine Boards	5
Paint and Stain	-
Quick Setting Cement	10

** Board dimensions are "nominal." Actual dimensions are smaller due to lumber industry standards. Cuts are actual length.*

Tools Used



Orbital Sander



Level



Tape Measure



Hedge Trimmer



Safety Glasses

Auger

Battery Tip: A 4.0Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

Assembly Instructions

Step 1

Purchase all materials

Step 2

Use auger to dig holes for 4x4 support beams. Note: dig holes as deep as 1/3 of the height of your support beams. (Example: a 6' tall wall would need at least 2' hole)

Step 3

Place 4x4 support beam in hole, ensure it is level, and then secure in place with quick setting concrete

Step 4

If painting the 4x4 beams, this would be a good time to do so!

Step 5

Use 20V circular saw to cut 1x6 planks into (3), 2" wide pieces. Alternatively, you could buy 1x2", but lumber inflation is currently up 400%, and this is more affordable. This also gives you the flexibility of customizing your design!