

# HART™



## Picture Ledge

Astra Spanbauer | [@redbrickfauxfarmhouse](https://www.instagram.com/redbrickfauxfarmhouse)

## PROJECT PLAN

**Finished Dimensions:** 34"L x 1"H x 3"D

**Skill Level:** Beginner

# Materials

Item	Qty
1" x 3" x 8' Board*	2
1" x 2" 8' Board*	1
1-1/2" 18-Gauge Brad Nails	1 box
1-1/4" 18-Gauge Brad Nails	1 box
Wood Screws	1 box
Stain	1 can
Wood Glue	1 tube

\* Board dimensions are "nominal." Actual dimensions are smaller due to lumber industry standards. Cuts are actual length.

A select/premium board or plywood comes with a smoother surface finish. It is clear or has very few tight knots, and it will have straight and sharp edges. This grade of wood pairs well with other boards or panels better and requires less time to sand and finish.

# Tools Used



Miter Saw



Drill/Driver



Orbital Sander



Brad Nailer



Tape Measure



I-Beam Level



Safety Glasses


Carpenter's  
Pencil

Work Table &  
Clamps

Battery Tip: A 4.0Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

# Lumber Cut List

Board*	Description	Cut To	Qty
1" x 3" x 8' Board*	Back & Base	34"	2
1" x 2" 8' Board*	Front	34"	1

\* Board dimensions are "nominal." Actual dimensions are smaller due to lumber industry standards. Cuts are actual length.

## Assembly Instructions

### Step 1

Cut down your boards to the measurements in the lumber cut list above. Our shelves are 36" in length, but you can make them longer or shorter to suit your space.

### Step 2

Attach the two 1x3 boards with wood glue or brad nailer with 1-1/2" nails every 10 inches.

### Step 3

Attach the 1x2 to the front with wood glue or brad nailer with 1-1/4" nails every 10 inches.

### Step 4

Fill nail holes with wood filler. Let dry and lightly sand.

### Step 5

Apply a wood stain of your choice.

### Step 6

Locate studs in your wall and use two screws to attach the picture ledge to the wall.