

# HART™



## SUNBURST MIRROR

@MrsDIY\_

# PROJECT PLAN

Skill Level: Beginner

# Materials

Item	Qty
Small shims (12 pack)	16
Hot glue sticks	10-15
Wood glue	1
Round 8" mirror	1
8" wood embroidery hoop	1
Wire wall hanging kit	1
Gorilla epoxy glue	1

# Tools Used



*Hot Glue Gun*



*Impact Driver*



Battery Tip: A 4.0 Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

# Assembly Instructions

---

## Step 1

Assemble your glue gun and allow to heat up.

---

## Step 2

Assemble the first part of the “flare” by lacing the side shims about  $\frac{1}{2}$ ” below the top shim and then glue together using the hot glue gun.

---

## Step 3

Assemble 2 side pieces and then glue all 3 pieces together using the hot glue gun.

---

## Step 4

Repeat these steps 16 times.

---

## Step 5

Assemble the flares by placing an additional shim in between each flare, about  $\frac{1}{2}$ ” above the end of the flare as shown below.

---

## Step 6

Douse the entire thing in wood glue and then rub it in with a glove, allowing it to dry for a couple hours.

---

## Step 7

Using the gorilla epoxy glue, glue the mirror to the center of the sunburst.

---

## Step 8

Glue the round embroidery hoop around the mirror using hot glue gun.