

HART™



WALL JEWELRY ORGANIZER

@livinginadvance

PROJECT PLAN

Skill Level: Beginner

Materials

Item	Qty
1/2"x 1-1/2" x 4' select pine boards	3
1/2" x 2" x 1'	1
1/2" wooden dowel	1
1" wooden dowel	1
Wood finishing screws	20
Screw-in hooks	16
Wood Glue	1
Pencil	1

Tools Used



Circ Saw



Drill



Orbit Sander



Tape Measure



Drill Bits



Battery Tip: A 4.0 Ah battery is recommended to be paired with high amp draw tools for maximum efficiency.

Assembly Instructions

Step 1

The first step is to cut the top width and middle width of the 1/2"x1-1/2" board to 12" using the circular saw. Then the bottom width of the 1/2"x2" board to 12". The bottom piece is wider and will be used as the bottom "tray".

Step 2

Next, you will need to cut the length of the right and left sides using 1/2"x1-1/2" board to 16".

Step 3

Now you can start assembling the rack into shape. Connect the top pieces to the side pieces making right angles. Once they are lined up, drill 2 5/64" pilot holes on each end with the drill. This prevents the boards from splitting when drilling screws into them.

Once the pilot holes are made you can drill 2 finishing screws on each end to connect the boards.

Step 4

Once the frame has been put together, the middle pieces can be cut to size. The upper middle piece will be cut to 8". Attach this piece using pilot holes and screws like the frame.

Step 5

Next cut the 1" wooden dowel to 9-1/2" and the 1/2" wooden dowel to 3".

Step 6

To attach the dowels together you will need to drill a 1/2" hole in the center of the 1" wooden dowel. Then add glue to the hole and stick the 1/2" dowel inside the hole you just drilled. While the glue is drying, repeat this process in the middle row of the organizer for the dowels to hang on.

Step 7

Once everything is put together, you can start adding the screw-in hooks. Measure them out so they are evenly placed on each section. Drill a 1/16" pilot hole on each mark and hand screw the hooks in.

Step 8

Now it is time to do a finish coat with polyurethane and a foam brush.

Step 9

Once the finish has dried, screw on mounting brackets to the back of each corner.

Step 10

Finally, mount it and add your favorite jewelry pieces.